



Tubular Front End Kit

Not To Scale

Mount The Shock Mounts On Top Outside Edge Of The Frame. Center The Mounts On The Centerline Of Front-End.

If Using Stock Frame And The Frame Rails Are Not Parallel To The Centerline Of The Car, Trim The Control Arm Mounts So The Control Arm Bolt Stays Parallel With The Centerline Of The Car.

